Practical No-1

<u>Aim :-</u> Understanding the Sensor Node Hardware. (For Eg. Sensors, Nodes(Sensor mote), Base Station, Graphical User Interface.

Components

A wireless sensor network (WSN) is a hardware and software package that typically consists of four parts (see Figure 1):

1. 'Sensors' connected to each node by a wired connection. In our case, we use sensors that can measure soil moisture, electrical conductivity, soil temperature, water pressure, flow rate, or a range of weather variables (light, air temperature, wind, humidity, etc.).



Figure 2. One of many sensors that can be connected to a node, this EC--5 sensor (Decagon Devices, Inc. Pullman, WA) measures volumetric water content(soil moisture).

2. 'Nodes' collect the data from sensors and transmit that to a 'base station'

computer using a one-way (in the case of monitoring) or two--way (in the case of monitoring and control) radio. Nodes can simply monitor environmental andsoil conditions or can be used to make control decisions. For example, some nodes have the capability to control an electric valve, such as an irrigation valve.



Relay switch,
used to control
irrigation valve(s), is
located here.

Figure 3. This nR5 (Decagon Devices, Inc. Pullman, WA) node is powered off of 5- AA batteries and is connected to 5 soil moisture sensors via stereo ports. The nR5node is also capable of controlling irrigation valve(s), based on user-defined settings.

- 3. 'Base Station' computer connects the system to the internet, so that data collected by the nodes, then transmitted to the base station computer, can be viewed anywhere an internet connection is available.
- 4. 'Graphical User Interface' is the web--based software package, that allows the data collected by sensors to be viewed. The software is also used to set irrigation parameters.



Figure 4. The graphical user interface above depicts the volumetric water content (soilmoisture) as horizontal lines and irrigation events and amounts as bars. Notice the increase in soil moisture after each irrigation event.

Not every WSN will have all four components, but to get optimal functionality the systems developed as part of this project do.

A very simple WSN example that many can relate to is that of the wireless environmental monitoring system used by the National Weather Service (NWS). You have probably seen these at a local airport or school. In this case, sensors measure environmental conditions and send this data to a node that wirelessly transmits the datausing a cell signal or wireless signal to a base--station computer where NWS employees(and you) can view the current temperature (or rainfall/dew point, wind, etc.) via awebsite or application ('app').



Figure 5. Typical environmental monitoring sensors that you would see at a National Weather Service (NWS) monitoring station. These same components can be used in a wireless sensor network by a specialty crop producer.

Practical No – 2


<u>Aim:-</u> Using Packet Tracer, create a wireless network of multiple PCs using appropriate accesspoint.

Steps:


Step 1: From the left corner of bottom toolbar select 'Selection On Left Most Panel in Bottom Toolbar' and then from the right hand side panel select 'Selection On Adjacent Panel' drag and drop devices on Canvas. Refer table below

Selection On Left	Selection On Adjacent	Device ID
MostPanel in Bottom	Panel	
Toolbar		
End Devices	PC-PT	PC0
End Devices	Laptop-PT	Laptop0
End Devices	SmartPhone-PT	SmartPhone0
Wireless Devices	AccessPoint-PT	AccessPoint0


Your Canvas should look as shown in figure below



Step 2: Click on **PC0** in **Physical** tab view Physical view of CPU is shown. **Switch OFF** the CPU and then remove the **PT-HEADPHONE** module from CPU and then add **WMP300N** module to CPU and **Switch ON** the CPU.




Step 3: Click on **Laptop0** in **Physical** tab view Physical view of Laptop is shown. **Switch OFF** the Laptop and then remove the **PT-HEADPHONE** module from Laptop and then add **WMP300N** module to Laptop and **Switch ON** the Laptop.




Step 4: Click on **PC0>>Desktop>>IP Configuration** a window as shown in figure should appear onyour screen. Assign IP Address, Subnet Mask, Default Gateway to PC0 and similarly for **Laptop0**.


Device ID	IP Address	Subnet mask	Default
			Gateway
PC0	192.168.1.1	255.255.255.0	192.168.1.10
Laptop0	192.168.1.2	255.255.255.0	192.168.1.10



Step 5: After adding hardware module and setting IP Address **PC0** and **Laptop0** must have been connect to **AccessPoint0**. Your Canvas should be as shown in figure below




Step 6: Click On AccessPoint0>>Config>>Port 1. Assign SSID=Network, and in frame Authentication select WPA2-PSK assign Pass Phrase of your choice(e.g. 123456789) to AccessPoint0.




Step 7: Click On PC0>>Desktop>>Wireless Connections a window as shown in figure should appear on your screen. Click On Connect>>Refresh. SSID of AccessPoint0 should appear in list of available connections. Click On SSID of AccessPoint0 and then Click on Connect.




Step 8: After clicking on **Connect** a dialog box as shown in figure below will appear asking for **Pass Phrase.** Enter the **Pass Phrase**(e.g. 123456789)and then Click On **Connect**. Similarly Connect **Laptop0** to **Access Point0**



Step 9: Click On **Smartphone0>>Config>>Wireless0** a window as shown in figure should appear on your screen. Enter **SSID** of **AccessPoint0**(e.g. Network) and then in Authentication frame select **WPA2-PSK** and enter **Pass Phrase**(e.g. 123456789).



Step 10: Verify your network by sending messages from one PC to another. From Right hand side toolbar select "**Simple Empty PDU**". Drop PDU on one End Device and then on another End Device on Canvas. In PDU list window, if Last Status is shown as "**Successful**" then consider that your network is working properly.



Practical No – 3

<u>Aim:-</u> Create and simulate a simple ad hoc network

Modules: 1) 2 PC

2) 2 Router

Background:

- 1. An ad hoc network is one that is spontaneously formed when devices connect and communicate with each other. The term ad hoc is a Latin word that literally means "for this," implying improvised or impromptu.
- 2. Ad hoc networks are mostly wireless local area networks (LANs). The devices communicate witheach other directly instead of relying on a base station or access points as in wireless LANs for data transfer coordination. Each device participates in routing activity, by determining the route using therouting algorithm and forwarding data to other devices via this route

